

INSTALLATION INSTRUCTIONS

Parts Included

- 2 Mounting Brackets • 2 Escutcheons • 2 Threaded Attachment Rings
- 2 Threaded Sleeves • 4 Wall Screws • 2 Anchors • Allen Wrench

Tools Needed

- Pencil • Drill • Measuring Tape • Screwdriver

1. Mark spot on wall where Flange will be attached.
2. Un-assemble Flange as shown in picture **(A.)**
 - a.) Un-thread "Threaded Sleeve" (1)
 - b.) Use Allen Wrench (5) provided to detach Ring (2)
 - c.) Un-thread Escutcheon (3)
3. Attach Mounting Bracket (4) to wall using anchors and screws provided.
4. Thread Escutcheon (3) onto Mounting Bracket (4) as shown in picture **(B.)**
5. Put Threaded Attachment Ring (2) onto Mounting Bracket (4) and tighten using Allen Wrench (5) provided as shown in picture **(C.)**
6. Thread "Threaded Sleeve" (1) onto Attached Ring (2) as shown in picture **(D.)**
7. Push shower rod into sleeve-internal O-Ring will hold rod in place.
8. We recommend use of ceiling supports to stabilize shower rod.

